

80071-FULL/QUEEN BED REPAIR KITS ASSEMBLY INSTRUCTION



80071-FULL/QUEEN BED <https://youtu.be/aaHLyic4IBk>

Scan QR Code for Assembly Instruction video or call customer service for video file.

IMPORTANT : PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"

"DO NOT OVERTIGHT ANY HARDWARE"


WARNING : SMALL PARTS AND HARDWARE NOT FOR CHILDREN UNDER 3 YEARS. ADULT ASSEMBLY REQUIRED.

TABLE OF CONTENTS


HARDWARES LIST	PAGE 2
PARTS LIST	PAGE 3
PARTS' LOCATION	PAGE 4
ASSEMBLY STEPS	PAGE 5 - 7
ASSEMBLY COMPLETED	PAGE 8

ASSEMBLY TOOLS REQUIRED

1. Screwdriver (not provide)



2. Hammer (not provide)



ATTENTION

1. Two-Person Installation Recommendation:









We strongly recommend that two people collaborate to install the repair kit. This ensures efficiency and safety during the installation process.

2. Regular Screw Tightness Check:

As part of regular maintenance, it is advised to check the tightness of all screws every 6-8 weeks. This helps maintain the stability and durability of your bed frame.

80071-FULL/QUEEN BED REPAIR KITS ASSEMBLY INSTRUCTION








HARDWARES LIST

ITEM	DESCRIPTION	DRAWING	QTY
A	JCBC SCREW M8 x 20MM		8 PCS
B	JCBC SCREW M6 x 35MM		24 PCS
D	SPRING WASHER M6 x 12MM		24 PCS
E	FLAT WASHER M6 x 19MM		24 PCS
F	CSK C/B SCREW (M4 x 32MM)		8 PCS
G	M5 ALLEN KEY (65MM)		1 PC
H	M4 ALLEN KEY (65MM)		1 PC
I	SUPPORT LEG ADJUSTABLE FEET		4 PCS

*Additional hardware included


80071-FULL/QUEEN BED REPAIR KITS ASSEMBLY INSTRUCTION

PARTS LIST

ITEM	DESCRIPTION	DRAWING	QTY
6	SIDE RAIL (L)		2 PCS
7	SIDE RAIL (R)		2 PCS
8	SIDE RAIL SUPPORT		4 PCS
9	SIDE RAIL LEG		2 PCS
20	SLAT		2 ROLL
21	CENTER SUPPORT		2 PCS
22	SUPPORT LEG WITH HANGER BOLT		4 PCS


80071-FULL/QUEEN BED REPAIR KITS ASSEMBLY INSTRUCTION

PARTS ' LOCATION




80071-FULL/QUEEN BED REPAIR KITS ASSEMBLY INSTRUCTION

STEP 1 Please follow the instructions from step 1 to step 3 to assemble the repair kits.




STEP 2




80071-FULL/QUEEN BED REPAIR KITS ASSEMBLY INSTRUCTION

STEP 3




STEP 4

Please follow the instructions from step 4 to step 8 to disassemble the existing bed in order to replace the repair kits.




80071-FULL/QUEEN BED REPAIR KITS ASSEMBLY INSTRUCTION

STEP 5




STEP 6

REMOVE THE EXISTING SIDE RAIL SET,
AND THEN REPLACE IT WITH THE NEW SIDE RAIL SET.




80071-FULL/QUEEN BED REPAIR KITS ASSEMBLY INSTRUCTION

STEP 7



STEP 8



ASSEMBLY COMPLETED

IMPORTANT

Discarding Original Components:

After successfully installing the repair kit, please discard the original components. This ensures that the bed frame operates according to the latest specifications.